


# EVERCOUCH™

Covering EverCouch Tapered Arms

## LEFT & RIGHT COVER LABELS




Left

Right


Arm Covers are labeled "LEFT ARM" and "RIGHT ARM". Make sure you are using the correct Cover for each Arm before starting.

## AVOID CONNECTION ZONE




**Important:** Cover must avoid overlapping onto connection zone (highlighted above in red) or EverCouch will not assemble properly.

## 1 Slide Cover over Arm




- Locate Covers labeled "Right Arm" and "Left Arm". Match Cover labels with labels on Arm Inserts.
- Align top four corners and pull Cover over Arm, ensuring top is tight.
- Secure Cover using hook and loop strips starting at the top of the Arm, ensuring Cover does not extend onto connection zone.
- Continue to secure hook and loop strips down the Arm aligning corners and edges.
- Align corners of the Cover and hook and loop strips ensuring all seams are straight.
- Secure ends of Cover.

## 2 Secure hook and loop on the bottom



Flip Arm over to secure Cover to the bottom. Pull Cover tight to align seams and edges.

## 3 Check Cover alignment



Once the Cover is securely fastened, inspect to make sure all edges are nice and straight. You're ready to assemble your EverCouch!