

## **StealthTech Bluetooth Chipset Upgrade**

### **Requirements:**

1. Windows Based Laptop or Computer
2. 3-6ft Micro-USB to USB A Data Cable
  - a. If you do not have one, one can be updated here:
  - b. <https://www.amazon.com/Amazon-Basics-Charging-Transfer-Gold-Plated/dp/B07232M876/?th=1>
3. Disable Anti-Virus Applications on Windows Computer
4. Copy the Micro USB Upgrade folder to the Windows PC (on a Desktop or a Folder of your choosing), and leave all the files and applications in the same folder together, do not separate them.

### **BT Upgrade Instructions**

1. Confirm the remote control is connected/paired to the ST Center Channel and the Center Channel power is on.
2. Obtain the 3-6ft Micro-USB Data Cable for the software update.
3. Connect the StealthTech Center Channel via the Service Port with the Windows PC via the Micro-USB Cable in Step 2.
4. Press and hold the “MODE” + “BT” buttons on the remote control at the same time for more than 12 seconds until the Red LED on the remote control turns off.
5. Next, press 'Volume +' on the remote control for 5 seconds or more; when there are no volume LEDs displayed on the ST Center Channel, this means that the Center Channel has now entered into the upgrade mode; otherwise, repeat step 4 to ensure the CC (Center Channel), is in upgrade mode.

